


Measuring for a replacement toilet suite



S-Trap set-out


S-Trap set-out

Measure the distance from the wall to the center of the floor waste outlet.

P-Trap set-out

Measure the distance from the floor to the center of the wall waste outlet.

Set-out:.....mm




Back inlet

Positioned at the rear of the cistern. Measure the height from the floor to the center of the inlet, and the width from the center of the toilet suite to the center of the outlet.

Height:.....mm

Width:.....mm



Bottom inlet

May be positioned on either the left or right side. Measure the height from the floor to the center of the inlet, and the width from the center of the toilet suite to the center of the outlet.

Height:.....mm

Width:.....mm